



CONTINUOUS INSULATION ATTACHMENT. AIR-BARRIER PERFORMANCE.

The Thermal-Grip® ci Prong Washer is a large 2" diameter solid cap washer that attaches rigid insulation and helps seal against air / moisture penetration through the weather barrier assembly. Dual prongs enable pre-spotting for on-the-wall screw assembly. Flexible perimeter flattens without tearing insulation facer. Self-drilling or HiLo thread screws with ceramic coating for corrosion resistance. Use Grip-Lok® Autofeed Fastening System for rapid attachment.

PRODUCT FEATURES

- Pre-spotting prongs = no hand assembly required!
- UV inhibitor for exposure during course of construction.
- 2" dia. solid plastic cap design for air-barrier performance.
- Stiffened center ring prevents screw pull-through.
- Flexible perimeter flattens without tearing insulation facer.
- Optional use with Grip-Lok® Autofeed Fastening System with Bullseye® nose adaptor.
- Use with Grip-Deck® ci ceramic coated screws.
- Attaches ALL types of rigid insulation and mineral wool.
- Specified, tested or approved by all insulation manufacturers.
- Made in USA. Patented and/or patent pending.



AVAILABLE WITH BULK OR COLLATED GRIP-DECK® SCREWS

Use with Grip-Lok® Autofeed Fastening System with Bullseye® nose adaptor for rapid attachment.

Grip-Deck® Self-Drilling or HiLo Thread Screws available in bulk or collated.



SINCE 1823

ALTENLOH, BRINCK & CO. US, INC.
ALTENLOH, BRINCK & CO. - GROUP

